



## FHX 9840: Softswitch IAD Terminal Real-time Charging Server

### Introduction:

FHX 9840 Softswitch IAD Terminal Real-time Charging Server is specially designed as the pair software for FHX 1000 IAD. In general, it is applied in IP supermarket and telephone bar, etc. It can manage the real-time charging of IAD terminal.



### Main Functions:

- Real-time charging: receive the charging command and the charging information from IAD, and after filtering and processing it, charge according to the charging standards defined by the users.
- Call control: the system is able to cut the ongoing call at any time.
- Charging standard configuration: provide the users with the configuration and charging standards of multiple call types.
- Phone configuration: the maximum number of the phone supported by the system is 500 currently, and how a phone is connected with IAD determines how the phone should be configured.
- Call record query: operators can query the records of each call at any time.
- Output report: print various reports according to the needs of the users.

### Features:

- General mode of charging standard configuration: accord with the charging standard of domestic telecom operators.
- Real-time charging and real-time call control.
- Compatibility: adopt standard protocol and the intercommunication with IAD devices of other manufacturers is good.
- Two-level power management: two power levels of system administrator and ordinary operator, with good security.

### Configuration Requirements:

- Hardware configuration: Common PC
- Operation system: Microsoft Windows2000, Microsoft Windows XP